


STUDYING DESK - G0223IT0241
Klaxon Madrid Studying Desk (Asian Walnut & Black)

Installation Instructions

1. This product should only be installed by someone who fully understand the installation instructions.
2. Make sure that the supporting surface will safely support the combined load of the equipment, hardware & components
3. Never exceed the maximum load capacity.
4. Always use assistant or mechanical lifting equipment, if needed, to safely lift & position equipment.
5. Tighten screws firmly, but do not over-tighten. Over-tightening can damage the screw & reduce their holding power
6. This product is intended for indoor use only. Using this product outdoors could lead to product failure & personal injury.

Component Checklist




Installation Steps


STEP 1

FIX ALL Minifix-Screws and Minifix-Drums:

MINIFIX SET




DRUM INSERTING



Note: Make sure Drum inserting as same as above, Drum arrow direction at side surface hole side.

SCREW INSERTING




Note: Tight the screw clock-wise till the thread disappear.

STEP 2

Unlock Mode:

Note: Make sure all the given points otherwise it will not fix properly.

**Minifix-Drum
Arrow at Hole
Side Before
Inserting Minifix-Screw**




STEP 3

Lock Mode:

Note: Tight all Minifix-Drum Properly.


**Tight Minifix-Drum
Clock-wise
Till It Stops
and Fits properly**



STEP 4

Connect C With E:


Note: Tight all Minifix-Drum Properly.



STEP 5

Connect E With B:


Note: Tight all Minifix-Drum Properly.



STEP 6

Connect D With C & B:


Note: Tight all Minifix-Drum Properly.



STEP 7

Connect A to Above Set with C & B:

Note: Tight all Minifix-Drum Properly.



INSTALLATION GUIDE

STUDYING DESK - G0223IT0241
Klaxon Madrid Studying Desk (Asian Walnut & black)

G0223IT0241-242

